



JWBS-9

Band Saw

10000850M
230/50/1

PARTS LIST

Walter Meier (Fertigung) AG

Bahnstrasse 24

8603 Schwerzenbach

Switzerland

Phone +41 44 806 47 48

Fax +41 44 806 47 58


jetinfo.eu@waltermeier.com

www.jettools.com



P-10000850M 2009/08/28

Parts Breakdown For JWBS-9 Band Saw



Parts List For JWBS-9 Band Saw

Index No.	Part No.	Description	Size	Qty.
1	JWBS9-001	Screw		13
2	JWBS9-002	Washer		13
3	JWBS9-003	Hinge plate		2
4	JWBS9-004	Cover		1
5	JWBS9-005	Blind nut		8
6	JWBS9-006	Buckle spring		2
7	JWBS9-007	Clamp bracket		2
8	JWBS9-008	Screw		8
9	JWBS9-009	Lock button		2
10	JWBS9-010	Saw blade		1
11	JWBS9-011	Retaining ring		2
12	JWBS9-012	Bearing		4
13	JWBS9-013	Drive wheel		1
14	JWBS9-014	Up guard board B		1
15	JWBS9-015	Drive wheel		1
16	JWBS9-016	Bolt		1
17	JWBS9-017	Bracket		1
18	JWBS9-018	Gear		1
19	JWBS9-019	Bearing		2
20	JWBS9-020	Shaft		1
21	JWBS9-021	Guide B		2
22	JWBS9-022	Screw		4
23	JWBS9-023	Guide A		2
24	JWBS9-024	Support		1
25	JWBS9-025	Screw		4
26	JWBS9-026	Up guard		1
27	JWBS9-027	Spring washer		4
28	JWBS9-028	Up guard board A		1
29	JWBS9-029	Adjustment block A		3
30	JWBS9-030	Screw		1
31	JWBS9-031	Screw		1
32	JWBS9-032	Bushing		1
33	JWBS9-033	Spindle		1
34	JWBS9-034	Adjustment block B		1
35	JWBS9-035	Spring pin		1
36	JWBS9-036	Switch		1
37	JWBS9-037	Switch plate		1
38	JWBS9-038	Screw		5
39	JWBS9-039	Brush		1
40	JWBS9-040	Wheel tire		1
41	JWBS9-041	Synchro-cog belt wheel B		1
42	JWBS9-042	Synchro-belt		1
43	JWBS9-043	Synchro-cog belt wheel A		1
44	JWBS9-044	Shaft		1
45	JWBS9-045	Pin		1
46	JWBS9-046	Tension knob		1
47	JWBS9-047	Washer		1
48	JWBS9-048	Spring seat		1
49	JWBS9-049	Cylinder compress spring		1
50	JWBS9-050	Body		1
51	JWBS9-051	Base		1
52	JWBS9-052	Washer		4
53	JWBS9-053	Washer		4
54	JWBS9-054	Hex screw		4
55	JWBS9-055	Low guard		1
56	JWBS9-056	Nut		1
57	JWBS9-057	Indicator		1
58	JWBS9-058	Low guard board		1
59	JWBS9-059	Bolt		4
60	JWBS9-060	Washer		4
61	JWBS9-061	Spring washer		4

Parts List For JWBS-9 Band Saw

Index No.	Part No.	Description	Size	Qty.
62	JWBS9-062	Miter guafe body		1
63	JWBS9-063	Washer		1
64	JWBS9-064	Knob		1
65	JWBS9-065	Nut		1
66	JWBS9-066	Wing-nut		1
67	JWBS9-067	Screw		1
68	JWBS9-068	Screw		1
69	JWBS9-069	Work table		1
70	JWBS9-070	Guide bar		1
71	JWBS9-071	Pointer		1
72	JWBS9-072	Screw		1
73	JWBS9-073	Table insert		1
74	JWBS9-074	Bolt		2
75	JWBS9-075	Motor		1
76	JWBS9-076	Knob		1
77	JWBS9-077	Washer		1
78	JWBS9-078	Spring		1
79	JWBS9-079	Knob		1
80	JWBS9-080	Tracking knob		1
81	JWBS9-081	Joint base		1
82	JWBS9-082	Screw		2
83	JWBS9-083	Nut		1
84	JWBS9-084	Cord bush		1
85	JWBS9-085	Cord		5
86	JWBS9-086	Press cord nip		2
87	JWBS9-087	Screw		1
88	JWBS9-088	Cover plate		1
89	JWBS9-089	Strain relief		1
90	JWBS9-090	Power cord		1
91	JWBS9-091	Knob		1
92	JWBS9-092	Rubber washer		1
93	JWBS9-093	Miter gauge		1
94	JWBS9-094	Guide mirror		1
95	JWBS9-095	Screw		1
96	JWBS9-096	Micro-switch housing		1
97	JWBS9-097	Micro-switch		1
98	JWBS9-098	Fixed plate		2
99	JWBS9-099	Micre-switch cover		1
100	JWBS9-100	Screw		2
101	JWBS9-101	Lame base		1
102	JWBS9-102	Nut		1
103	JWBS9-103	Washer		1
104	JWBS9-104	Lame base cover		1
105	JWBS9-105	Screw		2
106	JWBS9-106	Screw		2
107	JWBS9-107	Press cord nip		1
108	JWBS9-108	Screw		2
109	JWBS9-109	Wire bush		1
110	JWBS9-110	Lame cover		1
111	JWBS9-111	Clamp lever		1
112	JWBS9-112	Cotter pin		1
113	JWBS9-113	Connecting bolt		1
114	JWBS9-114	Flat washer		1
115	JWBS9-115	Rubber washer		1
116	JWBS9-116	Fixed clamp		1
117	JWBS9-117	Washer		2
118	JWBS9-118	Bolt		2
119	JWBS9-119	Flat washer		1
120	JWBS9-120	Compress spring		1
121	JWBS9-121	Clamper		1
122	JWBS9-122	Flat washer		1
123	JWBS9-123	Connecting rod		1
124	JWBS9-124	Fence		1