



MBS-910CSP Miter Bandsaw

MBS-910CSP.... 50000313T 3~400V, 50Hz

PARTS LIST


JPW (Tool) AG.
Ackerstrasse 45
CH-8610 Uster
Switzerland

www.jettools.com

P-50000313T

2019-05


MBS-910CSP Stand Assembly



MBS-910CSP Stand Assembly

Index No.	Part No.	Description	Size	Q'ty
1.....	MBS-910CSP-1.....	Base (Right Part).....		1
1-1.....	TS-1492041E.....	Hex. Cap Bolt.....	M12x40.....	2
1-2.....	MBS-910CSP-1-2.....	Nut.....	M12.....	2
1-3.....	TS-1491021E.....	Hex. Cap Bolt.....	M10x20.....	4
1-4.....	MBS-910CSP-1-4.....	Washer.....	10x25x2.....	4
2.....	MBS-910CSP-2.....	Plate.....		1
2-1.....	TS-1502011E.....	Hex. Socket Cap Screw.....	M5x8.....	4
3.....	MBS-910CSP-3.....	Base (Rear Part).....		1
4.....	MBS-910CSP-4.....	Base (Front Part).....		1
4-1.....	TS-1504031E.....	Hex. Socket Cap Screw.....	M8x16.....	8
4-2.....	MBS-910CSP-4-2.....	Washer.....	8x18x2.....	8
5.....	MBS-910CSP-5.....	Base (Left Part).....		1
6.....	MBS-910CSP-6.....	Water Proof Plate.....		1
6-1.....	MBS-910CSP-6-1.....	Knob.....	M8x30.....	2
7.....	MBS-910CSP-7.....	Coolant and Chip Tray.....		1
8.....	TS-1491021E.....	Hex. Cap Bolt.....	M10x20.....	4
9.....	MBS-910CSP-9.....	Washer.....	10x25x2.....	4
10.....	MBS-910CSP-10.....	Support Plate.....		1
10-1.....	TS-1490041E.....	Hex. Cap Bolt.....	M8x25.....	2
11.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20.....	2
12.....	MBS-910CSP-12.....	Spring Washer.....	M8.....	2
13.....	MBS-708CSP-13.....	Material Support Plate.....		1
14.....	TS-1491021E.....	Hex. Cap Bolt.....	M10x20.....	2
15.....	MBS-910CSP-15.....	Spring Washer.....	M10.....	2
16.....	MBS-910CSP-16.....	Washer.....	10x25x2.....	2
17.....	MBS-910CSP-17.....	Coolant Plate.....		1
18.....	MBS-708CSP-18.....	Filter Net.....		1
19.....	MBS-910CSP-19.....	Nut.....	M12.....	2
20.....	TS-1492041E.....	Hex. Cap Bolt.....	M12x40.....	2
21.....	MBS-910CSP-21.....	Plug.....	M3/8".....	1
22.....	TS-2245102E.....	Socket HD Button Screw.....	M5x10.....	4
23.....	MBS-708CSP-23.....	Pump.....	32W 400V 1 Ph.....	1
24.....	MBS-910CSP-24.....	Hose Clamp.....	13mm.....	1
25.....	MBS-910CSP-25.....	Hose.....	5/16x130cm.....	1
26.....	MBS-910CSP-26.....	Washer.....	6x13x1.....	2
27.....	TS-1503061E.....	Hex. Socket Cap Screw.....	M6x25.....	2
28.....	EHB-350DGSVIP-22-5.....	Coolant Plate.....		1
29.....	EHB-350DGSVIP-22-6.....	Thumb Knob.....	M6x10.....	2
30.....	MBS-910CSP-30.....	Cover.....		1
30-1.....	TS-1503021E.....	Hex. Socket Cap Screw.....	M6x12.....	1
30-2.....	MBS-910CSP-30-2.....	Spring Washer.....	M6.....	1
168.....	MBS-708CSP-29.....	Speed Switch Selector.....		1
169.....	MBS-708CSP-30.....	Power Indicator Light.....		1
170.....	MBS-708CSP-31.....	Start Button.....		1
171.....	MBS-708CSP-32.....	Stop Button.....		1
172.....	MBS-708CSP-33.....	Emergency Switch.....		1
173.....	MBS-910CSP-173.....	Hole Cover.....		1
174.....	MBS-910CSP-174.....	Panel.....		1
175.....	MBS-708CSP-34.....	Button Head Socket Screw.....	M5x8.....	8
176.....	MBS-910CSP-176.....	Main Power Switch.....		1
177.....	MBS-708CSP-38.....	Contactor.....	C-12D.....	1
178.....	MBS-910CSP-178.....	Overload Relay.....		1
179.....	MBS-910CSP-179.....	Bottom Plate.....		1
180.....	MBS-708CSP-42.....	Transformer.....	0V 400V 26VA.....	1
181.....	MBS-708CSP-40.....	Fuse.....	2A.....	1
183.....	MBS-708CSP-37.....	Grounding Plate.....		1


MBS-910CSP Swivel & Base Assembly



MBS-910CSP Swivel & Base Assembly

Index No.	Part No.	Description	Size	Q'ty
32	MBS-910CSP-32	Swivel Arm		1
32-1	MBS-910CSP-32-1	Limit Switch Cover		1
32-2	MBS-910CSP-32-2	Washer	8x18x2	1
32-3	TS-1504031E	Hex. Socket Cap Screw	M8x16	1
33	TS-1491031E	Hex. Cap Bolt	M10x25	1
34	MBS-910CSP-34	Pivot		1
35	MBS-910CSP-35	Anti-Dust Cover	30mm	2
36	BB-32006E	Bearing	32006	2
37	MBS-910CSP-37	Nut	M10	2
38	TS-1491031E	Hex. Cap Bolt	M10x25	1
39	MBS-910CSP-39	Spring Hook		1
40	MBS-910CSP-40	Nut	M12	1
41	MBS-910CSP-41	Star Washer	M30	1
42	MBS-910CSP-42	Nut	M30	1
43	MBS-910CSP-43	Scale		1
43-1	MBS-910CSP-43-1	Rivet	2.3x4	2
44	MBS-910CSP-44	Disk		1
45	TS-1504061E	Hex. Socket Cap Screw	M8x30	4
46	MBS-910CSP-46	Spring Washer	M8	4
47	MBS-910CSP-47	Oil Seal	4mmx518mm	1
48	MBS-910CSP-48	Shaft		1
49	MBS-910CSP-49	Nut		1
50	TS-1503061E	Hex. Socket Cap Screw	M6x25	1
51	MBS-910CSP-51	Bushing		1
52	MBS-910CSP-52	Oil Inlet	1/16"	2
53	MBS-910CSP-53	Locking Lever		1
53-1	MBS-910CSP-53-1	Rubber Hander		1
57	MBS-910CSP-57	Hand Wheel	6-1/2"	1
58	MBS-910CSP-58	Set Screw	M8x10	1
59	MBS-910CSP-59	Nut	M20	1
59-1	MBS-910CSP-59-1	Set Screw	M5x5	1
60	MBS-910CSP-60	Bearing Bushing		1
61	BB-51104E	Bearing	51104	1
62	MBS-910CSP-62	Lock Handle		1
63	MBS-910CSP-63	Bushing		1
64	TS-1524021E	Set Screw	M8x10	1
65	TS-2236911E	Hex. Socket Cap Screw	M6x100	2
66	MBS-910CSP-66	Movable Vise		1
67	MBS-910CSP-67	Plate		1
68	TS-1514021E	Flat Head Machine Screw	M6x16	2
69	MBS-910CSP-69	Compressed Spring	5x31x35mm	1
70	MBS-910CSP-70	Lead Screw		1
70-1	MBS-910CSP-70-1	Key	5x5x15	1
71	MBS-910CSP-71	Washer	8x18x2	1
72	TS-1504031E	Hex. Socket Cap Screw	M8x16	1
73A	MBS-910CSP-73A	Vise Table		1
74	TS-1524021E	Set Screw	M8x10	1
75	MBS-910CSP-75	Scale Point		1
75-1	MBS-910CSP-75-1	Hex. Socket Cap Screw	M5x8	2
76	MBS-708CSP-82	Length Rod		1
77	MBS-910CSP-77	Stop Plate		1
77-1	TS-1523041E	Set Screw	M6x12	1
78	MBS-910CSP-78	Knob	M6x10	1
79	MBS-1013CSD-95-4	Stop Bar		1

MBS-910CSP Bow Assembly




MBS-910CSP Bow Assembly

Index No.	Part No.	Description	Size	Q'ty
80.....	MBS-910CSP-80.....	Saw Arm.....		1
81.....	MBS-910CSP-81.....	Gear Box.....		1
82.....	MBS-910CSP-82.....	Vent Screw.....		1
83.....	MBS-910CSP-83.....	Key.....	7x7x25.....	1
84.....	MBS-910CSP-84.....	Spring Washer.....	M10.....	4
85.....	TS-1505061E.....	Hex. Socket Cap Screw.....	M10x40.....	4
86.....	MBS-910CSP-86.....	Motor.....	0.75kW 400V 3 Ph.....	1
87.....	MBS-910CSP-87.....	Junction Box.....		1
88.....	MBS-910CSP-88.....	Key.....	6x6x30.....	1
89.....	MBS-910CSP-89.....	Spring Washer.....	M8.....	4
90.....	TS-1490051E.....	Hex. Cap Bolt.....	M8x30.....	4
91.....	MBS-910CSP-91.....	Drive Flywheel.....		1
92.....	MBS-910CSP-92.....	Washer.....		2
93.....	MBS-910CSP-93.....	Spring Washer.....	M10.....	2
94.....	TS-1491031E.....	Hex. Cap Bolt.....	M10x25.....	2
95.....	MBS-910CSP-95.....	Idle Flywheel.....		1
96.....	BB-6006ZZE.....	Bearing.....	6006ZZ.....	2
97.....	MBS-910CSP-97.....	Shaft.....		1
98.....	MBS-910CSP-98.....	Tension Shaft.....		1
99.....	MBS-910CSP-99.....	Thrust Spring Washer.....		4
103.....	MBS-910CSP-103.....	Handle Wheel.....		1
104.....	MBS-708CSP-124.....	Handle.....		2
105.....	MBS-910CSP-105.....	Plate.....		1
106.....	MBS-910CSP-106.....	Washer.....	6x13x1.....	2
107.....	TS-1503031E.....	Hex. Socket Cap Screw.....	M6x12.....	2
108.....	MBS-910CSP-108.....	Limit Switch.....	TW-8111.....	1
109.....	TS-1501071E.....	Hex. Socket Cap Screw.....	M4x25.....	2
110.....	MBS-910CSP-110.....	Handle.....		1
112.....	MBS-910CSP-112.....	Rod.....		1
113.....	MBS-910CSP-113.....	Slide.....		1
114.....	MBS-910CSP-114.....	Nut.....	M16.....	1
115.....	MBS-910CSP-115.....	Washer.....		1
116.....	MBS-910CSP-116.....	Spring Washer.....	M10.....	1
117.....	TS-1491031E.....	Hex. Cap Bolt.....	M10x25.....	1
118.....	MBS-910CSP-118.....	Gib.....		1
119.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20.....	3
120.....	MBS-910CSP-120.....	Front Ball Bearing Bracket.....		1
121.....	MBS-910CSP-121.....	Set Screw.....	M5x5.....	4
122.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20.....	2
123.....	MBS-910CSP-123.....	Setting Bracket.....		1
123-1.....	MBS-910CSP-123-1.....	Press Plate.....		1
124.....	TS-1504051E.....	Hex. Socket Cap Screw.....	M8x25.....	2
125.....	MBS-910CSP-125.....	Handle.....		1
126.....	TS-1503011E.....	Hex. Socket Cap Screw.....	M6x8.....	1
127.....	MBS-910CSP-127.....	Plastic Handle.....	M6x60.....	1
128.....	TS-1524021E.....	Set Screw.....	M8x10.....	2
129.....	TS-1523041E.....	Set Screw.....	M6x12.....	4
130.....	TS-1504051E.....	Hex. Socket Cap Screw.....	M8x25.....	2
131.....	MBS-910CSP-131.....	Limit Switch.....		1
131-1.....	MBS-910CSP-131-1.....	Switch Pin.....		1
132.....	TS-1501081E.....	Hex. Socket Cap Screw.....	M4x30.....	2
133.....	MBS-910CSP-133.....	Blade.....	27x0.9x2460 5/8T.....	1
134.....	MBS-910CSP-134.....	Blade Cover.....		1
135.....	MBS-910CSP-135.....	Knob Bolt.....	M6x10.....	4
135-1.....	MBS-910CSP-135-1.....	Spacer (not shown).....	#12.....	4
136.....	MBS-910CSP-136.....	Round Head Screw.....	M4x8.....	2
137.....	MBS-910CSP-137.....	Nut.....	M4.....	2

Index No.	Part No.	Description	Size	Q'ty
138.....	MBS-708CSP-148.....	T Connector.....		1
139.....	MBS-910CSP-139.....	Pipe Fitting	1/4Px5/16	2
140.....	MBS-910CSP-140.....	Hose	5/16x90cm.....	1
141.....	TS-1502041E	Hex. Socket Cap Screw	M5x16.....	2
142.....	MBS-910CSP-142.....	Coolant Switch	1/4Px5/16	1
143.....	MBS-910CSP-143.....	Hose Clamp.....	13mm	1
144.....	MBS-910CSP-144.....	Hose	5/16x40cm.....	1
145H-1	MBS-910CSP-145H-1	Spring Shaft.....		1
145H-2	MBS-910CSP-145H-2	Setting Plate		1
145H-3	MBS-910CSP-145H-3	Handle		1
145H-4	MBS-910CSP-145H-4	Nut.....	M16	2
145H-5	MBS-910CSP-145H-5	Bushing		1
145H-6	MBS-910CSP-145H-6	Adjustable Shaft	16x160mm.....	1
145H-7	MBS-910CSP-145H-7	Spring	6x50x188mm.....	1
145H-8	TS-1524021E	Set Screw	M8x10.....	3
145H-9	MBS-910CSP-145H-9	Washer	16x30x3.....	1


MBS-910CSP Bearing Guide Assembly



MBS-910CSP Bearing Guide Assembly

Index No.	Part No.	Description	Size	Q'ty
147	MBS-910CSP-147	Rear Ball Bearing Seat		1
148	MBS-910CSP-148	Front Ball Bearing Seat		1
149	MBS-910CSP-149	Steel Pin	8x30	2
150	MBS-910CSP-150	Rear Blade Guard		1
151	TS-1504011E	Hex. Socket Cap Screw	M6x8	1
152	MBS-910CSP-152	Eccentric Shaft		2
153	BB-608ZZE	Bearing	608ZZ	8
154	MBS-910CSP-154	Nut	M8	4
155	MBS-910CSP-155	Spring Washer	M8	4
156	MBS-910CSP-156	E Ring	E-7	4
157	MBS-910CSP-157	Centric Shaft		2
158	BB-608ZZE	Bearing	608ZZ	2
159	MBS-910CSP-159	Pipe Fitting	1/4Px5/16	2
160	MBS-910CSP-160	Hex. Socket Cap Screw	M5x8	1
161	MBS-910CSP-161	Front Blade Guard		1
162	MBS-910CSP-162	Bracket		1
165	MBS-910CSP-165	Washer	6x13x1	2
166	TS-1482021E	Hex. Cap Bolt	M6x12	2
167	MBS-910CSP-167	Brush	Ø 50	1

MBS-910CSP Hydraulic Cylinder Assembly



MBS-910CSP Hydraulic Cylinder Assembly

Index No.	Part No.	Description	Size	Q'ty
189.....	MBS-910CSP-189.....	Top Support.....		1
190.....	TS-1482031E.....	Hex. Cap Bolt.....	M6x16.....	2
191.....	MBS-910CSP-191.....	Spring Washer.....	M6.....	2
192.....	TS-1504051E.....	Hex. Socket Cap Screw.....	M8x25.....	2
193.....	MBS-708CSP-11-1.....	Spring Washer.....	M8.....	2
194.....	MBS-910CSP-194.....	Bottom Support.....		1
195.....	MBS-910CSP-195.....	Spring Washer.....	M8.....	2
196.....	TS-1504041E.....	Hex. Socket Cap Screw.....	M8x20.....	2
197.....	TS-1523041E.....	Set Screw.....	M6x12.....	1
198.....	MBS-910CSP-198.....	Support Rod.....		1
199.....	MBS-910CSP-199.....	Hydraulic Cylinder.....		1
200.....	TS-1505061E.....	Hex. Socket Cap Screw.....	M10x40.....	1
202.....	MBS-910CSP-202.....	Limit Switch.....	TW-8111.....	1
203.....	MBS-910CSP-203.....	Round Head Screw.....	M5x10.....	2
204.....	MBS-910CSP-204.....	Cylinder Cover.....		1
205.....	MBS-708CSP-21H-18.....	Flat Washer.....	6x13x1.....	2
206.....	TS-1503011E.....	Hex. Socket Cap Screw.....	M6x8.....	2

